

Ashes (con't)

On the CC600 Series and CC501 Models (without grate and ash tray) the ashes should be removed regularly to avoid excessive buildup in the fire chamber and to avoid primary air passage blockage. The ashes should be removed after the fire has died out. It is advisable to have the flue pipe damper at a minimum setting or closed to avoid excessive air flow over ashes during removal.

DISPOSAL OF ASHES

Ashes should be placed in a metal container with a tight fitting lid. The closed container of ashes should be placed on a noncombustible floor or on the ground, well away from all combustible materials, pending final disposal. If the ashes are disposed of by burial in soil or otherwise locally dispersed, they should be retained in the closed container until all cinders have thoroughly cooled.

FIRE SCREEN

Your COUNTRY COMFORT stove has been provided with a spark screen. This screen must be used if the stove is being operated with the doors open, to prevent hot sparks from popping out of the stove onto a flammable surface, such as a rug. Note: The CC501 stove is not intended to be operated with door open, therefore it has no spark screen provided.

CAUTION! The cabinet, cast iron doors, and other parts of the stove and flue pipe get very hot when the stove is in use. Fireproof gloves should be worn at all times when tending the fire, removing ashes or any other time direct contact with hot parts is possible.

If at anytime your stove or connector pipe begins to glow, you are over-firing. Immediately turn the thermostatically controlled damper to low (check to see that the draft door shuts) and close the secondary air intake (except Model CC501). Do not add fuel or open drafts until the glowing stops and the unit has cooled.

MAINTENANCE INSTRUCTIONS

1. At the beginning of each heating season - the stove, connector pipe and chimney should be inspected to see that it is in good working condition. The connector pipe and chimney should be cleaned of soot, creosote, and other residues.
2. The firebrick lining of your stove should be checked at least once a year. All broken firebricks should be replaced. New firebrick can be obtained from your COUNTRY COMFORT dealer.
3. Failure to maintain or properly use the appliance may cause a house fire.

The address of the NFPA is Batterymarch Park, Quincy, MA 02269. Some additional publications of interest from the NFPA are as follows:

Heat Producing Appliance Clearances (NFPA #89M)
Chimneys, Fireplaces and Vents (NFPA #211)

Reprints and excerpts from NFPA 221, 1977 are reprinted with permission, National Fire Protection Association, Batterymarch Park, Quincy, MA 02269

COUNTRY COMFORT APPLIANCE LIMITED WARRANTY

Under the conditions of this warranty, the manufacturer of the COUNTRY COMFORT appliance warrants that the appliance is free from defects in material and workmanship for normal home use. The obligation under this warranty shall be limited to repair and/or replacement of any part or parts of the appliance which prove defective under normal home use and service within five (5) years from the date of sale of the appliance to the original purchaser and which shall be found defective by the manufacturer or its authorized agent. This warranty is expressly in lieu of all other warranties expressed or implied, including warranties by statute, operation of law, or otherwise.

Manufacturer assumes no obligations or liabilities except as stated in this limited warranty which is provided for the purpose of stating the total obligations and liabilities under which manufacturer sells the appliance and to provide the original purchaser with an express, extended limited warranty. No person is authorized to bind manufacturer to any obligation or liability and this warranty expresses the legal obligations of the manufacturer to the original purchaser. No obligation is assumed with respect to any other party. Manufacturer assumes no liability or obligation for any unit or accessory altered by purchaser.

This warranty does not apply to this appliance or any part thereof which has been subject to accident, negligence, alterations, abuse or misuse even if used only for home applications. The manufacturer, Orrville Products, Inc., makes no warranty whatsoever in respect to accessories or parts not manufactured by Orrville Products, Inc., and which bear the name of the actual manufacturer. As to such items, the limited warranty of the accessory or part, to the extent allowed, is transferred from Orrville Products, Inc., to the original purchaser. Paint finish, fire brick and glass are expressly excluded from this warranty. Cast iron grates will carry a one (1) year warranty.

The original purchaser, as used in this warranty, shall be that person to whom the COUNTRY COMFORT appliance is originally sold for home use.

This warranty shall be effective only if the original purchaser of the COUNTRY COMFORT appliance is registered with Orrville Products, Inc., by sending this warranty form to Orrville Products, Inc., within thirty (30) days of the date of purchase or the date upon which the original purchaser takes possession of the appliance, whichever comes first. Such registration or the failure to register shall not be deemed to create any obligation or liability by the manufacturer and this warranty with its conditions and limitations shall be the only procedure for obtaining any rights against the manufacturer and expresses the sole obligations and responsibilities of the manufacturer which are offered to the original purchaser and accepted upon purchase of the appliance.

Any cause of action by the original purchaser against the manufacturer under this warranty can be only at the situs of Orrville Products, Inc., and the laws of the State of Ohio shall be applicable to this warranty.

LISTED NO. _____

COUNTRY COMFORT REGISTRATION CARD

NAME OF PURCHASER _____

ADDRESS _____

CITY _____ State _____ Zip _____

DEALER NAME _____

PRICE (LESS TAX) _____ DATE PURCHASED _____

MODEL _____

MAIL WITHIN THIRTY (30) DAYS OF PURCHASE